## Installation and Operating Guide OUDELONG Air Shower



#### **Proprietary Notice**

This manual pertains to proprietary devices manufactured by OUDELONG. Neither this document nor any portion of it may be reproduced in any way without prior written permission from OUDELONG.

#### Safety Notice

A thorough familiarity with all operating guidelines is essential to safe operation of the product. Failure to observe safety precautions could result in poor performance, damage to the system or other property, or serious bodily injury or death.

The following symbols are intended to call your attention to two levels of hazard involved in operation:

The information presented here is subject to change without notice.

OUDELONG makes no warranties applying to information contained in this manual or its suitability for any implied or inferred purpose. OUDELONG shall not be held liable for any errors this manual contains or for any damages that result from its use



Cautions are used when failure to observe instructions could result in significant damage to equipment



Warnings are used when failure to observe instructions or precautions could result in injury or death.

#### 1.0 Introduction

This manual provides information on installing and operating your OUDELONG Air Shower. By studying this document carefully, you can be assured of a long, efficient service life from the unit.

Read all of the instructions before operating your unit.

Pay particular attention to all safety precautions.

Retain this Installation and Operating Guide for future reference.





To reduce the risk of fire, electric shock, or injury to persons, use this unit only in the manner intended by OUDELONG.



WARNING

Before servicing or cleaning your Air Shower, switch off the power at the service panel and lock the service disconnect to prevent the system from being accidentally switched back on. If the service disconnect cannot be locked, attach a visible warning sign to the service panel.

### 2.0 Description

OUDELONG's Air Shower remove surface-deposited particles from personnel as they enter and exit a cleanroom or other controlled environment. These units are rated to exceed ISO 5 particle count standards.

Air Showers use one (1) HEPA Filtration System Blower Module(s) to achieve this contaminant removal.

The Blower Module circulates air at a very high speed through nozzles positioned throughout the interior walls of the Air Shower. Each nozzle can be adjusted to control the direction of the air flow. A highcapacity HEPA filter (rated to be 99,99% efficient @ 0.3-micron particles and installed with a dosed-cell gasket)captures contaminants before air is forced through the nozzles.

The Air Shower is equipped with electro-magnetic interlocks that keep both doors locked during the operation cycle to prevent outside disturbance and contamination. After the cycle, both doors will unlock to allow entry and exit. The cycle can then commence again after a delay time has passed.

There are total two (3) Emergency Stop Buttons (1 located inside and 2 located outside the Air Shower). Either button cuts power to the Blower Module(s), stops the blower cycle and allows either door to be opened.

Low-energy 12W LED lights are positioned along the ceiling of the Air Shower/Tunnel. Operation is controlled by a switch on the PLC touch screen control panel located on the exterior of the unit.



#### 3.0 Installation



TOTAL BOND, INCOMENT OF TRABBUT AND ALL BROWN MAY, IN SECTION OF A MAKE AN ARRAY OF THE PARTY OF

**Uniteding Shipment** 

to Many, or realize representative descrip-

Secretaria de la companya del la companya de la com

**Contact** 

oudelongsales04@163.com/ WhatsApp: (+86) 139 1273 1080 For FULL document download

The fit Transe is present the section of the Special Conference for the second present and present and present in

I had the factor or alter to called speak in the base perceivage supported through may be represent to the in-center find a source for the region for countries of the final f

I then a recording on the form a retrieval or particular active at most model, such against to record the diagram abstraction with a mass again.

THE DESCRIPTION OF THE OWNER, AND ADDRESS OF THE PARTY OF

100 o hold, postor for tr. Drawn's algorisos for their extregio.
 100 for sall, an insplice autom's application for all and travel to expect to expect for salls, all for rail.

4.0 Operation

Overview
 Ne automatic control system of the air allower room of the control system.

The automatic operating bean of the air observe comthe inner and outer doors, than and trop of lighting. the fan. Vision prompts and other functions during all during the automatic process, and has finding function

mather/soard button description

Contact

oudelong<mark>sales0</mark>4@163.com/ WhatsApp: (+86) 139 1273 1080

For FULL document download

٠

A. Builtion description of the control panel of the air shower room.

I beging strike to \$ 000\$, in the control panel of the air shower room.

I series of an example of the control of the series of the control of the

The street colors for the colors of the colo

to become factors. Dath belowed they be not seen and company to the company to

I temporarigin. De montage and construction and construct

serigin (in 1994) the management of

# Contact oudelongsales04@163.com/ WhatsApp: (+86) 139 1273 1080 For FULL document download

The county is a face of the county of the co

The first of the second second

A first transport with a contract of the state of the contract transport of the state of the sta

15% to come if a fine of commercial to a fine original, bridge above 1813. \$1986

Martin Notice and an artist for all the state of the stat

The course of the contract of the course of

design for all from 100, the fits observed every 1. If against our lighty from 2 to 10.00 figures in 1 against the

property to acres, I as provide with I painty I affin more unbroadly on all to acres, one

Cognition and Speciality Stock

3. Operational instructions Licinose con opering presiden

the same of the sa

1. All of course of the sales of

1. Name the other wide

I or from that workly promite string species

1. No come time served reductive service. It

per come the same parties for the purpose

Fire district. No page outcomes was be proven also

responsible species with our in the at these creates.

To an income to seem officers or coming to the property of the seem of the see

Left To Spilling is a constrained college after the integration de-

places and Transport Television Sect.

SHAPE NA

# Contact oudelongsales04@163.com/ WhatsApp: (+86) 139 1273 1080 For FULL document download



hotelistics and Spending built

5.0 Maintenance

State of the continuous and forgotty of all



Description of the party of the state of the

The last could need it in the first best death of the last could be the last could b

Mills Statement To sortic of the Manage part in State with the

## Contact

oudelongsales04@163.com/ WhatsApp: (+86) 139 1273 1080 For FULL document download

6.0 Warranty

a de Bassa

Book to serve, a process of your district of your process of process.

Thank you for ordering from